

*It's All about Building a
Better Product for Our Clients!*

Chiller Interface from Web Browser

Control Your Chiller from Any Computer on Your Network!




*Note: Chiller
Ethernet Switch
Required.*




*Visit us at:
www.jmchillers.com*

1. Verify the chiller is connected to your network via cat5 or cat6 cable.



2. On the home screen, touch the **Feature Control** button on the right side of the screen.

3. Touch the **Network Setup** button on the Chiller Features Control Screen.




Chiller Interface from Web Browser:

4. You can use the current IP addresses or assign new static IP addresses for your network.
5. If you decide to assign new IP addresses you will need qty 2 static IP addresses for your network.
6. Update the default subnet mask and default gateway for both the touch screen and PLC.




IMPORTANT: *When updating the IP addresses on this screen, the IP address at the bottom of the touch screen side that says “**Host (PLC) Address**” must match the “**Current IP Address**” for the PLC Network settings. **Failure to match these IP addresses will cause the touchscreen to lose communication with the PLC screen and PLC.***



7. Confirm all settings and touch the **Update Settings** button at the bottom of the screen when ready.

8. Open a web browser and type in the IP address for the touch screen. You will now see the chiller and will be able to control from your computer remotely.

Username: **Download**
 Password: **1122**



*It's All about Building a
Better Product for Our Clients!*

Have Questions? Give Us a Call at: **888-539-1731**

Fax: 267-203-8786

Email: info@jmchillers.com

Website: www.jmchillers.com