
Auto Fluid Makeup



J&M Fluidics, Inc. 851 Tech Drive

Telford, PA 18969





Insulated Tank

Installed - Auto City Water Makeup Solenoid Valve

 The Auto City Water Makeup Solenoid Valve physically starts and stops the fluid flow to the tank.



Auto

Fluid Makeup Solenoid Valve

 The Auto Level Switch tells the Auto **City Water Makeup Solenoid Valve** when the flow of fluid to the tank should turn on or off.

Have more questions?

Call or Email: info@jmchillers.com

J&M Fluidics Inc. • Ph (888) 539-1731 • Fx (267) 203-8786 • www.jmchillers.com